


**BOSCH**

SMS2012SD/08-EU1, weiss

GESCHIRRSPÜLGERÄTE
StandgeräteIdent – Nummern – Konstante
3740


51 3600
Gebrauchsanweisung
 (D,GB,F,I,NL,E,P)
51 3779
Montageanweisung
 (D,GB,F,I,NL,DK,
 E,P,S,N,SF,GR,TR)

- 1) 02 9941
- 2) 02 9029
- 3) 11 9795
- 4) 05 6860
- 5) 02 9944
Set
- 6) 05 6822
- 7) 02 9943
- 8) 02 9945
Set
- 9) 02 9002
Set



E161411-4/1

FAMILY : SMS2012SD
 MODEL NO: SMS2012SD/08
 Check Position No/Part No or Replacement No



E161411-4/2


FAMILY : SMS2012SD

MODEL NO: SMS2012SD/08

Check Position No/Part No or Replacement No

**BOSCH**

SMS2012SD/08—EU1, weiss

GESCHIRRSPÜLGERÄTE
StandgeräteIdent – Nummern – Konstante
3740

E161411–4/3

FAMILY : SMS2012SD

MODEL NO: SMS2012SD/08

Check Position No/Part No or Replacement No

Ident – Nummern – Konstante
3740

- 1) 01 9202
- 2) 11 0668
- 3) 05 6247

