


**BOSCH**SMS2011GB/01-GB1
SMS2011GB/03-GB2GESCHIRRSPÜLGERÄTE
StandgeräteIdent - Nummern - Konstante
Ident - Nummern - Konstante
3740

51 3600
Gebrauchsanweisung
(D,GB,F,I,NL,E,P)
51 3779
Montageanweisung
(D,GB,F,I,NL,DK,
E,P,S,N,SF,GR,TR)


- 1) 02 9941
- 2) 02 9029
- 3) 11 9795
- 4) 05 6860
- 5) 02 9944 Set
- 6) 05 6822
- 7) 02 9943
- 8) 02 9945 Set
- 9) 02 9002 Set

160794-4/1

FAMILY : SMS2011GB

MODEL NO: SMS2011GB/03

Check Position No/Part No or Replacement No

**BOSCH**SMS2011GB/01-GB1
SMS2011GB/03-GB2GESCHIRRSPÜLGERÄTE
Standgeräte

FAMILY : SMS2011GB

MODEL NO: SMS2011GB/03


Check Position No/Part No or Replacement No



BOSCH


SMS2011GB/01-GB1
SMS2011GB/03-GB2

GESCHIRRSPÜLGERÄTE
Standgeräte



Ident-Nummern – Konstante
Ident-Nummern – Konstante
3740

- 1) 02 9020
- 2) 05 7127
- 3) —
- 4) 08 6400
- 5) 02 7385
- 6) 08 6970
- 7) 04 3889

**BOSCH**SMS2011GB/01-GB1
SMS2011GB/03-GB2GESCHIRRSPÜLGERÄTE
Standgeräte

Ident-Nummern	Konstante	Ident-Nummern	Konstante
3740	...	3740	...

- 1) 01 9202
- 2) 11 0668
- 3) 05 6247