

**BOSCH**


SPI6326CH/01-CH1

GESCHIRRSPÜLGERÄTE
UnterbaugeräteMat. - Nr. - Konstante
3740

51 3712
Gebrauchsanweisung
(D,GB,F,I,NL,E,P)
51 3391
Montageanweisung
(D,CH,GB,F,I,NL,NL,
DK,P,E,S,N,SF,GR,TR)

- 1) 02 9058
2) 02 9060
3) 05 6223
Set

- 4) 02 9673
5) 08 6145
Set



e160422-3/1


FAMILY : SPI6326CH

MODEL NO: SPI6326CH/01

Check Position No/Part No or Replacement No

**BOSCH**

SPI6326CH/01-CH1

GESCHIRRSPÜLGERÄTE
UnterbaugeräteMat. - Nr. - Konstante
3740 1) 02 9017
Set

e160422-3/2


FAMILY : SPI6326CH

MODEL NO: SPI6326CH/01

Check Position No/Part No or Replacement No

**BOSCH**

SPI6326CH/01-CH1

GESCHIRRSPÜLGERÄTE
UnterbaugeräteMat. – Nr. – Konstante
3740

e160422-3/3

FAMILY : SPI6326CH

MODEL NO: SPI6326CH/01

Check Position No/Part No or Replacement No