


**BOSCH**SMS2012II/01-I1
SMS2012II/03-I2GESCHIRRSPÜLGERÄTE
StandgeräteIdent - Nummern - Konstante
3740

51 3600
Gebrauchsanweisung
 (D,GB,F,I,NL,E,P)
51 3779
Montageanweisung
 (D,GB,F,I,NL,DK,
 E,P,S,N,SF,GR,TR)

- 1) 02 9941
- 2) 02 9029
- 3) 11 9795
- 4) 05 6860
- 5) 02 9944
Set
- 6) 05 6822
- 7) 02 9943
- 8) 02 9945
Set
- 9) 02 9002
Set




160715-4/1

FAMILY : SMS2012II

MODEL NO: SMS2012II/01

Check Position No/Part No or Replacement No


**BOSCH**SMS2012II/01-I1
SMS2012II/03-I2GESCHIRRSPÜLGERÄTE
Standgeräte

160715-4/2

FAMILY : SMS2012II

MODEL NO: SMS2012II/01

Check Position No/Part No or Replacement No

**BOSCH**SMS2012II/01-I1
SMS2012II/03-I2GESCHIRRSPÜLGERÄTE
StandgeräteIdent – Nummern – Konstante
3740

160715-4/3

FAMILY : SMS2012II
 MODEL NO: SMS2012II/01
 Check Position No/Part No or Replacement No

**BOSCH**SMS2012II/01-I1
SMS2012II/03-I2GESCHIRRSPÜLGERÄTE
StandgeräteIdent – Nummern – Konstante
3740