










BOSCH

SMS2032/02-EU1, weiss
SMS2032EE/02-E1, weiss
SMS2032II/02-I1, weiss

GESCHIRRSPÜLGERÄTE
Standgeräte

Ident – Nummern – Konstante
3740



- 1) 02 9020
- 2) 05 7127
- 3) —
- 4) 08 6400
- 5) 02 7385
- 6) 08 6970
- 7) 04 3889


**BOSCH**

SMS2032/02-EU1, weiss
 SMS2032EE/02-E1, weiss
 SMS2032II/02-I1, weiss

GESCHIRRSPÜLGERÄTE
 Standgeräte

Ident – Nummern – Konstante
 3740

- 1) 01 9202
- 2) 11 0668
- 3) 05 6247



161214-4/4

FAMILY : SMS2032

MODEL NO: SMS2032/02

Check Position No/Part No or Replacement No