


**BOSCH**

SMS3082II/14-V01,weiß


GESCHIRRSPÜLGERÄTE
Standgeräte

e162262-4/1

FAMILY : SMS3082II

MODEL NO: SMS3082II/14


Check Position No/Part No or Replacement No

Ident - Nummern - Konstante
3740

- 1) 10 4298
PVC Ø5mm/2m
- 2) 02 5069
Set
- 3) 091058
kompl.
- 4) 02 9948
- 5) 02 9017
Set
- 6) 05 6826
- 7) 05 6827
- 8) —
- 9) 05 6806
- 10) 06 7827
55°C
- 11) 06 9132
66°C
- 12) 29 0501
2150W
- 13) 02 9954
85°C
- 14) 05 5164
Set

**BOSCH**

SMS3082II/14-V01,weiß

GESCHIRRSPÜLGERÄTE
StandgeräteIdent – Nummern – Konstante
3740

- 1) 02 9020
- 2) 05 7127
- 3) —
- 4) 08 6400
- 5) —
- 6) 09 5459
- 7) 02 9098

e162262-4/3


FAMILY : SMS3082II

MODEL NO: SMS3082II/14

Check Position No/Part No or Replacement No

**BOSCH**

SMS3082II/14-V01,weiß

GESCHIRRSPÜLGERÄTE
StandgeräteIdent - Nummern - Konstante
3740

e162262-4/4

FAMILY : SMS3082II

MODEL NO: SMS3082II/14

Check Position No/Part No or Replacement No