


Ident – Nummern – Konstante
3740

51 5414
Gebrauchsanweisung
EU1 – EU3
(D,GB,F,I,NL,E,P,DK)
51 3842
Montageanweisung
(D,GB,F,I,NL,DK,
E,P,S,N,SF,GR,TR)

- 1) 02 9941
- 2) 02 9029
- 3) 11 9996
- 4) 05 6860
- 5) 02 9944
Set
- 6) 05 6823
Set
- 7) 02 9673
- 8) 02 7091
- 9) 05 6822
- 10) 02 9943
- 11) 02 9945
Set
- 12) 02 9002
Set
- 14) 02 9056
rot
02 9055
grün




**BOSCH**

SMI3047/03-EU1, weiss
SMI3047/04-EU2, weiss
SMI3042EU/03-EU3, weiss

GESCHIRRSPÜLGERÄTE
Unterbaugeräte

Ident - Nummern - Konstante
3740



161198-4/2

FAMILY : SMI3047

MODEL NO: SMI3047/03


Check Position No/Part No or Replacement No

**BOSCH**

SMI3047/03-EU1, weiss
 SMI3047/04-EU2, weiss
 SMI3042EU/03-EU3, weiss

GESCHIRRSPÜLGERÄTE
 Unterbaugeräte

Ident – Nummern – Konstante
 3740




- 1) 05 4927
- 2) 11 9082
- 3) 05 6829
- 4) 08 6400
- 5) 02 7385
- 6) 08 6401
- 7) 04 3889

**BOSCH**

SMI3047/03-EU1, weiss
 SMI3047/04-EU2, weiss
 SMI3042EU/03-EU3, weiss

GESCHIRRSPÜLGERÄTE
 Unterbaugeräte

Ident – Nummern – Konstante
 3740



161198-4/4

FAMILY : SMI3047

MODEL NO: SMI3047/03

Check Position No/Part No or Replacement No