


**BOSCH**


SMS2042EE/14-V01,weiß

GESCHIRRSPÜLGERÄTE
StandgeräteIdent – Nummern – Konstante
3740 51 4136
Gebrauchsanweisung
(D,F,GB,I,NL)
51 3779
Montageanweisung
(D,F,GB,I,NL,DK,
E,P,S,N,SF,GR,TR)

- 1) 02 9941
- 2) 02 9029
- 3) 11 9795
- 4) 05 6860
- 5) 06 8956 Set
- 6) —
- 7) —
- 8) —
- 9) 06 6319
- 10) 02 9943
- 11) 02 9945 Set
- 12) 02 9002 Set

e162033-4/1

FAMILY : SMS2042EE
 MODEL NO: SMS2042EE/14
 Check Position No/Part No or Replacement No

Ident – Nummern – Konstante
3740

e162033-4/2


FAMILY : SMS2042EE

MODEL NO: SMS2042EE/14

Check Position No/Part No or Replacement No

**BOSCH**

SMS2042EE/14-V01,weiß

GESCHIRRSPÜLGERÄTE
StandgeräteIdent – Nummern – Konstante
3740

- 1) 02 9020
- 2) 05 7127
- 3) —
- 4) 08 6400
- 5) —
- 6) 08 6970
- 7) 02 9098

e162033-4/3

FAMILY : SMS2042EE

MODEL NO: SMS2042EE/14

Check Position No/Part No or Replacement No

Ident – Nummern – Konstante
3740