

**BOSCH**


SMI4022CH/01-CH1
SMI4022CH/02-CH2
SMI4022CH/03-CH3

SMI4022CH/04-CH4

GESCHIRRSPÜLGERÄTE
Unterbaugeräte

Ident-Nummern-Konstante
3740

51 3601
Gebrauchsanweisung
(D,GB,F,I,NL)
51 3842
Montageanweisung
(D,GB,F,I,NL,DK,
E,P,S,N,SF,GR,TR)



- 1) 02 9941
- 2) 02 9029
- 3) 11 9996
- 4) 05 6860
- 5) 02 9944 Set
- 6) 05 6823 Set
- 7) 02 9673
- 8) 02 7091
- 9) 05 6822
- 10) 02 9943
- 11) 02 9945 Set
- 12) 02 9002 Set

160725-4/1

FAMILY : SMI4022CH
MODEL NO: SMI4022CH/02
Check Position No/Part No or Replacement No


**BOSCH**

SMI4022CH/01-CH1
SMI4022CH/02-CH2
SMI4022CH/03-CH3

SMI4022CH/04-CH4

GESCHIRRSPÜLGERÄTE
Unterbaugeräte

Ident.-Nummern-Konstante
3740



160725-4/2

FAMILY : SMI4022CH
MODEL NO: SMI4022CH/02
Check Position No/Part No or Replacement No


**BOSCH**

SMI4022CH/01-CH1
SMI4022CH/02-CH2
SMI4022CH/03-CH3

SMI4022CH/04-CH4

GESCHIRRSPÜLGERÄTE
Unterbaugeräte

Ident-Nummern-Konstante
3740



- 1) 05 4927
- 2) 11 9082
- 3) 05 6829
- 4) 08 6400
- 5) 02 7385
- 6) 08 6401
- 7) 04 3889
- 8) 05 7134
CH1,CH2
02 9199
CH3,CH4

160725-4/3

FAMILY : SMI4022CH

MODEL NO: SMI4022CH/02

Check Position No/Part No or Replacement No

**BOSCH**


SMI4022CH/01-CH1
SMI4022CH/02-CH2
SMI4022CH/03-CH3

SMI4022CH/04-CH4

GESCHIRRSPÜLGERÄTE
Unterbaugeräte

Ident-Nummern-Konstante
3740

- 1) 01 9202
2) 11 0668
3) 05 6247



160725-4/4

FAMILY : SMI4022CH
MODEL NO: SMI4022CH/02
Check Position No/Part No or Replacement No