





Ident – Nummern – Konstante
3740

1) 35 1386
V01,V03,V05
35 2369
V02,V04,V06
Komplett


**BOSCH**WFB1604 – WFB1604PL/05–V01
WFB1604 – WFB1604BY/05–V02WFB1604 – WFB1604PL/06–V03
WFB1604 – WFB1604BY/06–V04WFB1604 – WFB1604PL/07–V05
WFB1604 – WFB1604BY/07–V06WASCHGERÄTE
Waschvollautomaten

e121525-4/2

FAMILY : WFB1604PL

MODEL NO: WFB1604PL/05

Check Position No/Part No or Replacement No

**BOSCH**WFB1604 – WFB1604PL/05–V01
WFB1604 – WFB1604BY/05–V02WFB1604 – WFB1604PL/06–V03
WFB1604 – WFB1604BY/06–V04WFB1604 – WFB1604PL/07–V05
WFB1604 – WFB1604BY/07–V06WASCHGERÄTE
WaschvollautomatenIdent – Nummern – Konstante
3740 1) Kohlebürste
15 1613
CESET
15 4071
SOLE

2) 09 3390


3) 28 3725
Kompl.* Schraubensatz
05 9132

e121525-4/3

FAMILY : WFB1604PL

MODEL NO: WFB1604PL/05

Check Position No/Part No or Replacement No

**BOSCH**WFB1604 – WFB1604PL/05–V01
WFB1604 – WFB1604BY/05–V02WFB1604 – WFB1604PL/06–V03
WFB1604 – WFB1604BY/06–V04WFB1604 – WFB1604PL/07–V05
WFB1604 – WFB1604BY/07–V06WASCHGERÄTE
WaschvollautomatenIdent – Nummern – Konstante
3740

1) 28 7065