





- 1) 26 7979
(HU)
26 7080
(CRO)
26 7082
(SLO)
26 7083
(SER)
26 7084
(GB)
26 7085
(CZ)

Mat. – Nr. – Konstante
3740

Gebrauchs-
Aufstellanweisung
52 3627
(PL)
52 3685
(CZ)
52 3686
(HU)
53 3687
(CRO)
52 3688
(SER)
52 3689
(SLO)
52 3696
(GB)

Programmtabelle
52 3630
(PL)
52 3690
(CZ)
52 3691
(HU)
52 3692
(CRO)
52 3693
(SER)
52 3694
(SLO)
52 3695
(GB)

2) 35 5745
(PL)
V01
35 5778
(Symbole)



e121643-4/2

FAMILY : WFL2060BY
MODEL NO: WFL2060BY/01
Check Position No/Part No or Replacement No

