






51 3600
Gebrauchsanweisung
(D,GB,F,I,NL,E,P)
51 3779
Montageanweisung
(D,GB,F,I,NL,DK,
E,P,S,N,SF,GR,TR)

- 1) 02 9941
- 2) 02 9029
- 3) 11 9795
- 4) 05 6860
- 5) 02 9944
Set
- 6) 05 6822
- 7) 02 9943
- 8) 02 9945
Set
- 9) 02 9002
Set



**BOSCH**SMS3025/01-EU1
SMS3025/03-EU2GESCHIRRSPÜLGERÄTE
StandgeräteIdent-Nummern-Konstante
3740


- 1) 02 9020
- 2) 05 7127
- 3) —
- 4) 08 6400
- 5) 02 7385
- 6) 08 6401
- 7) 04 3889

160833-4/3

FAMILY : SMS3025
MODEL NO: SMS3025/03
Check Position No/Part No or Replacement No

**BOSCH**SMS3025/01-EU1
SMS3025/03-EU2GESCHIRRSPÜLGERÄTE
StandgeräteIdent-Nummern-Konstante
3740

- 1) 01 9202
2) 11 0668
3) 05 6247



160833-4/4

FAMILY : SMS3025
MODEL NO: SMS3025/03
Check Position No/Part No or Replacement No